

EN



Nail Lamp User Manual

Non-Harmful To Hands!

01 PACKING LIST

- 1 UV LED Nail Lamp
- 2 Power Adapter
- 3 Instructions
- 4 Certificate

02 PARTS INSTRUCTION

- 1 Infrared induction
- 2 Power indicator light
- 3 10s timing button
- 4 30s timing button
- 5 60s timing button
- 6 99s painless mode button (Double power button)
- 7 Main body power port
- 8 Type-C 5V2A charging output port
- 9 USB-A 5V2A charging output port



03 PRODUCT INSTRUCTION

- 1 Designed for professional nail experts. Could perfect cure UV gel/Builder/LED gel.

04 OPERATOIN INSTRUCTION

- 1 Plug in power, and then connect the nail lamp. When plugged in power, the machine will start, and when unplugged, the machine will shut shown.



- 2 When the timing has not reached the key setting, press the timing key again to enter the standby state. All timing reset.
- 3 After the machine starts, you can select timers by pressing 10s/30s/60s/99s (low heat mode) buttons. When enter into low heat mode, power enhances gradually over time and resolve all pain problem caused by curing gels.
- 4 Double power function: after the machine starts, press any key for 10S/30S/60S, then press and hold the Double power key for 2-3 seconds to accelerate to 72W.
- 5 If user don't use the time setting buttons, Infrared sensor starts working when putting hands into the machine. Max working time lasts 120s.
- 6 When timing is working, the display light will show the corresponding time: 10s, 30s, 60s are countdown, 99s and infrared sensors are clockwise.

05 TECHNICAL INSTRUCTION

- 1 36 LEDs
- 2 Maximum power consumption: 72W
- 3 Rated input: 100- 240V 50/60Hz 1A
- 4 Size: 237x208x114mm
- 5 Wave length: 365+405nm

06 CAUTIONS

- 1 Please read the instruction carefully before using the lamp.
- 2 Please use the lamp correctly.
- 3 Not allow any liquid into the machine. Otherwise, damage may occur.
- 4 When timer button is out of function, please don't use.
- 5 Please unplug the adapter, when leaving.
- 6 Do not use the nail lamp when adapter failure happens.
- 7 Do not let the machine keep working for more than 600s, otherwise it may reduce the lifetime of nail lamp.
- 8 When using, please wear protective glasses and radiation protection suits.
- 9 The machine can detect internal temperature automatically during long term use. When the temperature is too high, the machine will turn into low-power operation, at the meanwhile the display light will show "07p" status. Timing stops working and return to normal power operation after the temperature get lower.